



EDUS 39 - 600 - F5

R-410A

Engineering Data

FXHQ-M
Ceiling Suspended Type



DAIKIN AC (AMERICAS), INC.

FXHQ-M Ceiling Suspended Type

1. Features	2
2. Specifications	3
3. Dimensions	4
4. Piping Diagrams.....	7
5. Wiring Diagrams.....	8
6. Electric Characteristics.....	9
7. Capacity Tables	10
7.1 Cooling Capacity	10
7.2 Heating Capacity	11
8. Air Velocity and Temperature Distributions.....	12
9. Sound Levels	15
10. Installation	16
11. Accessories	34

1. Features


External Appearance



Slim body with quieter and wider air flow

●Adoption of newly designed QUIET STREAM FAN

Uses the new quiet stream fan and many more quiet technologies.




●Low operating sound

Class	12	24	36
Operating sound (H/L)	42/38	44/42	46/42

(dB(A))


●Wide air discharge openings produce a spreading 100° air flow



●Maintenance is easy

●New Non-dew Louver

Bristle-free Louver minimizes contamination and makes cleaning simpler.



●Easy to clean flat design

●Maintenance is easier because everything can be performed from below the unit

●A long-life filter (maintenance free up to one year) is equipped as standard

2. Specifications

Ceiling Suspended Type


Model			FXHQ12MVJU	FXHQ24MVJU	FXHQ36MVJU
Cooling Capacity ¹	Btu/h		12,000	24,000	36,000
Heating Capacity ²	Btu/h		13,500	27,000	40,000
Casing Color			White (10Y9/0.5)	White (10Y9/0.5)	White (10Y9/0.5)
Dimensions: (H x W x D)		in (mm)	7-11/16x37-13/16x26-3/4" (177.8 x 954.9 x 679.5 mm)	7-11/16x55-1/8x26-3/4" (177.8 x 1400.2 x 679.5 mm)	7-11/16x62-5/8x26-3/4" (177.8 x 1590.7 x 679.5 mm)
Coil (Cross Fin Coil)	Rows x Stages x FPI		2x12x15	3x12x15	2x12x15+2x10x15
	Face Area	ft ² (m ²)	1.96' (0.60 m)	3.15' (0.96 m)	3.66+2.95' (1.11+0.90 m)
Fan	Model		3D12K1AA1	3D12K2AA1	
	Type		Sirocco Fan	Sirocco Fan	Sirocco Fan
	Motor Output	kW	0.06	0.13	0.13
	Air Flow Rate (H/L)	CFM	410/340	710/600	830/670
	Drive		Direct Drive	Direct Drive	Direct Drive
Temperature Control			Microprocessor Thermostat for Cooling and Heating	Microprocessor Thermostat for Cooling and Heating	Microprocessor Thermostat for Cooling and Heating
Sound Absorbing Thermal Insulation Material			Glass Wool	Glass Wool	Glass Wool
Air Filter			Resin Net (with Mold Resistant)	Resin Net (with Mold Resistant)	Resin Net (with Mold Resistant)
Piping Connections	Liquid Pipes	in (mm)	ϕ1/4" / 6.4 mm (Flare Connection)	ϕ3/8" / 9.5 mm (Flare Connection)	ϕ3/8" / 9.5 mm (Flare Connection)
	Gas Pipes	in (mm)	ϕ1/2" / 12.7 mm (Flare Connection)	ϕ5/8" / 15.8 mm (Flare Connection)	ϕ5/8" / 15.8 mm (Flare Connection)
	Drain Pipe	in (mm)	VP20 External Dia. 1" / 25.4 mm Internal Dia. 3/4" / 19.1 mm	VP20 External Dia. 1" / 25.4 mm Internal Dia. 3/4" / 19.1 mm	VP20 External Dia. 1" / 25.4 mm Internal Dia. 3/4" / 19.1 mm
Machine Weight (Mass)	Lbs		55	80	90
Sound Level (H) ⁴	dBA		42	44	46
Safety Devices			Fuse Thermal Protector for Fan Motor	Fuse Thermal Protector for Fan Motor	Fuse Thermal Protector for Fan Motor
Refrigerant Control			Electronic Expansion Valve	Electronic Expansion Valve	Electronic Expansion Valve
Connectable Outdoor Unit			R-410A Series	R-410A Series	R-410A Series
Standard Accessories			Operation Manual, Installation Manual, Drain Hose, Paper Pattern for Installation, Clamp Metal, Insulation for Fitting, Clamps, Washers.	Operation Manual, Installation Manual, Drain Hose, Paper Pattern for Installation, Clamp Metal, Insulation for Fitting, Clamps, Washers.	Operation Manual, Installation Manual, Drain Hose, Paper Pattern for Installation, Clamp Metal, Insulation for Fitting, Clamps, Washers.
Drawing No.			C:4D049326		

Notes:

- Nominal cooling capacities are based on the following conditions:
Return air temperature: 80°FDB, 67°FWB
Outdoor temperature: 95°FDB
Equivalent ref. piping: 25ft / 7.5 m (Horizontal)
- Nominal heating capacities are based on the following conditions:
Return air temperature: 70°FDB
Outdoor temperature: 47°FDB, 43°FWB
Equivalent ref. piping: 25ft / 7.5 m (Horizontal)
- Capacities are net, including a deduction for cooling (an addition for heating) for indoor fan motor heat.
- Anechoic chamber conversion value, measured under JISB8616 conditions. During actual operation, these values are normally somewhat higher as a result of ambient conditions.
- Refer to page 9 for Fan Motor Input.

3. Dimensions

FXHQ12MVJU




Number	Name	Description
1	Air discharge grille	
2	Air suction grille	
3	Air filter	
4	Gas pipe connection	φ 1/2 flare
5	Liquid pipe connection	φ 1/4 flare
6	Drain pipe connection	VP20
7	Ground terminal (inside the control box)	M4
8	Hanger bracket	
9	Cover for backward pipe connection	
10	Cover for upward pipe connection	
11	Right side drain pipe connection	knockout hole
12	Rear side drain pipe connection	knockout hole
13	Right side drain pipe connection	knockout hole
14	Hole in the wall for rear side pipe connection	
15	Conduit hole	φ 7/8
16	Upward gas pipe connection	φ 1-7/16
17	Upward liquid pipe connection	φ 1
18	Hole for transmission wiring	(φ 1-1/16)

3D049330

Note) 1. Location of name plate : Bottom of fan housing inside the suction grille.
 2. In case of using a wireless remote controller, this position will be the signal receiver. Refer to the drawing of wireless remote controller in detail.

FXHQ24MVJU




Number	Name	Description
1	Air discharge grille	
2	Air suction grille	
3	Air Filter	
4	Gas pipe connection	φ 5/8 flare
5	Liquid pipe connection	φ 3/8 flare
6	Drain pipe connection	VP20
7	Ground terminal (inside the control box)	M4
8	Hunger bracket	
9	Cover for backward pipe connection	
10	Cover for upward pipe connection	
11	Right side pipe connection	knockout hole
12	Right side drain pipe connection	knockout hole
13	Right side drain pipe connection	knockout hole
14	Hole in the wall for rear side pipe connection	
15	Conduit hole	φ 7/8
16	Upward gas pipe connection	φ 1-7/16
17	Upward liquid pipe connection	φ 1
18	Hole for transmission wiring	(φ 1-1/16)

3D049331

Note 1, Location of name plate : Bottom of fan housing inside the suction grille.
 2, In case of using a wireless remote controller, this position will be the signal receiver. Refer to the drawing of wireless remote controller in detail.

FXHQ36MVJU




Number	Name	Description
1	Air discharge grille	
2	Air suction grille	
3	Air filter	
4	Gas pipe connection	ø 5/8 flare
5	Liquid pipe connection	ø 3/8 flare
6	Drain pipe connection	VP20
7	Ground terminal (inside the control box)	M4
8	Hanger bracket	
9	Cover for backward pipe connection	
10	Cover for upward pipe connection	
11	Right side pipe connection	keocutout hole
12	Rear side drain pipe connection	keocutout hole
13	Right side drain pipe connection	keocutout hole
14	Hole in the wall for rear side pipe connection	
15	Conduit hole	ø 7/8
16	Upward gas pipe connection	ø 1-7/16
17	Upward liquid pipe connection	ø 1
18	Hole for transmission wiring	(ø 1-1/16)

3D049332

Note) 1. Location of name plate : Bottom of fan housing inside the suction grille.
 2. In case of using a wireless remote controller, this position will be the signal receiver. Refer to the drawing of wireless remote controller in detail.

4. Piping Diagrams




C:4D024460A

- R1T : Thermistor for suction air temperature
- R2T : Thermistor for liquid line temperature
- R3T : Thermistor for gas line temperature

Capacity	GAS	Liquid
12M	φ1/2"	φ1/4"
24/36M	φ5/8"	φ3/8"

5. Wiring Diagrams

FXHQ12MVJU
FXHQ24MVJU
FXHQ36MVJU



3D048116

6. Electric Characteristics

Units					Power supply		IFM		Input(W)	
Model	Type	Hz	Volts	Voltage range	MCA	MFA	KW	FLA	Cooling	Heating
FXHQ12M	VJ	60	208-230	MAX. 253 Min. 187	0.8	15	0.062	0.6	90	90
FXHQ24M					1.0	15	0.130	0.8	127	127
FXHQ36M					1.4	15	0.130	1.1	161	161

Symbols :

MCA : Min. Circuit Amps (A)
 MFA : Max. Fuse Amps (See note 5)
 KW : Fan Motor Rated Output(kW)
 FLA : Full Load Amps(A)
 IFM : Indoor Fan Motor

Note :

- Voltage range
Units are suitable for use on electrical systems where voltage supplied to unit terminals is not below or above listed range limits,
- Maximum allowable voltage unbalance between phases is 2%.
- MCA/MFA
 $MCA = 1.25 \times FLA$
 $MFA \leq 4 \times FLA$
 (Next lower standard fuse rating. Min. 15A)
- Select wire size based on the MCA.
- Instead of fuse, use Circuit Breaker.

C:4D049333

7. Capacity Tables

7.1 Cooling Capacity

FXHQ-M

		Cooling capacity											
Unit size	Outdoor air temp.	Indoor Air Temp. °FWB											
		61		64		67		70		72		75	
	°FDB	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC	TC	SHC
12	75	9.5	8.5	10.7	8.8	12.0	9.4	13.3	9.7	14.0	10.0	14.3	9.3
	79	9.5	8.5	10.7	8.8	12.0	9.4	13.3	9.7	13.8	9.6	14.0	9.3
	83	9.5	8.5	10.7	8.8	12.0	9.4	13.3	9.7	13.6	9.6	13.8	9.0
	87	9.5	8.5	10.7	8.8	12.0	9.4	13.2	9.6	13.3	9.3	13.6	9.0
	91	9.5	8.5	10.7	8.8	12.0	9.4	13.0	9.6	13.1	9.4	13.4	9.0
	95	9.5	8.5	10.7	8.8	12.0	9.4	12.7	9.4	12.9	9.3	13.1	8.9
	99	9.5	8.5	10.7	8.8	12.0	9.4	12.5	9.5	12.7	9.3	12.9	8.9
	103	9.5	8.5	10.7	8.8	12.0	9.4	12.3	9.2	12.4	8.8	12.7	8.7
24	75	18.9	15.3	21.5	16.6	24.0	17.1	26.5	17.8	28.0	18.1	28.5	17.2
	79	18.9	15.3	21.5	16.6	24.0	17.1	26.5	17.8	27.6	18.0	28.1	17.0
	83	18.9	15.3	21.5	16.6	24.0	17.1	26.5	17.8	27.1	17.7	27.6	16.8
	87	18.9	15.3	21.5	16.6	24.0	17.1	26.4	17.7	26.7	17.2	27.2	16.4
	91	18.9	15.3	21.5	16.6	24.0	17.1	25.9	17.5	26.2	17.2	26.7	16.6
	95	18.9	15.3	21.5	16.6	24.0	17.1	25.5	17.4	25.8	17.1	26.3	16.2
	99	18.9	15.3	21.5	16.6	24.0	17.1	25.0	17.1	25.3	16.9	25.8	16.1
	103	18.9	15.3	21.5	16.6	24.0	17.1	24.6	17.0	24.9	16.8	25.4	15.7
36	75	28.4	21.8	32.2	23.9	36.0	25.1	39.8	26.0	42.1	26.5	42.8	25.1
	79	28.4	21.8	32.2	23.9	36.0	25.1	39.8	26.0	41.4	26.1	42.1	24.7
	83	28.4	21.8	32.2	23.9	36.0	25.1	39.8	26.0	40.7	25.8	41.5	24.4
	87	28.4	21.8	32.2	23.9	36.0	25.1	39.5	26.0	40.0	25.5	40.8	24.4
	91	28.4	21.8	32.2	23.9	36.0	25.1	38.9	25.7	39.4	25.2	40.1	24.1
	95	28.4	21.8	32.2	23.9	36.0	25.1	38.2	25.3	38.7	24.6	39.4	23.7
	99	28.4	21.8	32.2	23.9	36.0	25.1	37.5	25.1	38.0	24.6	38.8	23.2
	103	28.4	21.8	32.2	23.9	36.0	25.1	36.8	24.8	37.3	24.3	38.1	22.8

TC : Total capacity ; kW
SHC : Sensible heat capacity ; kW



Refer to Outdoor Unit Capacity Tables : for the actual performance data of each indoor and outdoor unit combination.

7.2 Heating Capacity

FXHQ-M

Indoor unit	Outdoor Air Temp.		Indoor Air Temp. °FDB					
			62	65	68	70	72	75
			TC	TC	TC	TC	TC	TC
	°FDB	°FWB	MBh	MBh	MBh	MBh	MBh	MBh
12	22.0	20.0	11.7	11.7	11.6	11.6	11.6	11.6
	26.0	24.0	12.2	12.2	12.2	12.2	12.2	12.1
	30.0	28.0	12.8	12.8	12.7	12.7	12.7	12.3
	35.0	32.0	13.3	13.3	13.3	13.3	13.0	12.3
	39.0	36.0	13.9	13.9	13.9	13.5	13.0	12.3
	44.0	40.0	14.5	14.4	14.0	13.5	13.0	12.3
	47.0	43.0	14.9	14.7	14.0	13.5	13.0	12.3
	51.0	47.0	15.4	14.7	14.0	13.5	13.0	12.3
	54.0	50.0	15.5	14.7	14.0	13.5	13.0	12.3
	57.0	53.0	15.5	14.7	14.0	13.5	13.0	12.3
60.0	56.0	15.5	14.7	14.0	13.5	13.0	12.3	
24	22.0	20.0	23.3	23.3	23.3	23.2	23.2	23.2
	26.0	24.0	24.5	24.4	24.4	24.3	24.3	24.3
	30.0	28.0	25.6	25.5	25.5	25.5	25.4	24.5
	35.0	32.0	26.7	26.6	26.6	26.6	26.0	24.5
	39.0	36.0	27.8	27.7	27.7	27.0	26.0	24.5
	44.0	40.0	28.9	28.9	28.0	27.0	26.0	24.5
	47.0	43.0	29.7	29.5	28.0	27.0	26.0	24.5
	51.0	47.0	30.8	29.5	28.0	27.0	26.0	24.5
	54.0	50.0	31.0	29.5	28.0	27.0	26.0	24.5
	57.0	53.0	31.0	29.5	28.0	27.0	26.0	24.5
60.0	56.0	31.0	29.5	28.0	27.0	26.0	24.5	
36	22.0	20.0	35.0	35.0	34.9	34.8	34.8	34.7
	26.0	24.0	36.7	36.6	36.6	36.5	36.5	36.4
	30.0	28.0	38.4	38.3	38.2	38.2	38.1	36.8
	35.0	32.0	40.0	40.0	39.9	39.8	39.0	36.8
	39.0	36.0	41.7	41.6	41.6	40.0	39.0	36.8
	44.0	40.0	43.4	43.3	42.0	40.0	39.0	36.8
	47.0	43.0	44.6	44.2	42.0	40.0	39.0	36.8
	51.0	47.0	46.3	44.2	42.0	40.0	39.0	36.8
	54.0	50.0	46.5	44.2	42.0	40.0	39.0	36.8
	57.0	53.0	46.5	44.2	42.0	40.0	39.0	36.8
60.0	56.0	46.5	44.2	42.0	40.0	39.0	36.8	




Refer to Outdoor Unit Capacity Tables : for the actual performance data of each indoor and outdoor unit combination.


8. Air Velocity and Temperature Distributions

FXHQ12M <Cooling mode>

AIRFLOW DISTRIBUTIONS




TEMPERATURE DISTRIBUTIONS




FXHQ12M <Heating mode>

AIRFLOW DISTRIBUTIONS




TEMPERATURE DISTRIBUTIONS




FXHQ24M <Cooling mode>

AIRFLOW DISTRIBUTIONS




TEMPERATURE DISTRIBUTIONS




FXHQ24M <Heating mode>

AIRFLOW DISTRIBUTIONS




TEMPERATURE DISTRIBUTIONS




3D052939

FXHQ36M <Cooling mode>

AIRFLOW DISTRIBUTIONS




TEMPERATURE DISTRIBUTIONS




FXHQ36M <Heating mode>

AIRFLOW DISTRIBUTIONS




TEMPERATURE DISTRIBUTIONS



3D052940

9. Sound Levels

Overall



Notes:

Operation noise differs with operation and ambient conditions.


dBA

Model	208~230V, 60Hz	
	H	L
FXHQ12MVJU	38	33
FXHQ24MVJU	44	36
FXHQ36MVJU	46	41

Octave Band Level


○—○ 208V~230V

FXHQ12MVJU




4D052512

FXHQ24MVJU



4D052513


FXHQ36MVJU



4D052514

10. Installation

Installation Example



1. SAFETY CONSIDERATIONS

Read these **SAFETY CONSIDERATIONS** carefully before installing air conditioning equipment, and be sure to install it correctly. After completing the installation, make sure that the unit operates properly during the start-up operation.

Instruct the customer how to operate and maintain the unit. Inform customers that they should store this Installation Manual with the Operation Manual for future reference.

Always use a licensed installer or contractor to install this product. Improper installation can result in water or refrigerant leakage, electrical shock, fire, or explosion.

Meanings of DANGER, WARNING, CAUTION, and NOTE symbols are as follows:

- ! DANGER** Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
- ! WARNING** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
- ! CAUTION** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.
- ! NOTE** Indicates situations that may result in equipment or property damage accidents only.

! DANGER

- **Refrigerant gas is heavier than air and displaces oxygen. A massive leak can lead to oxygen depletion, especially in basements, and an asphyxiation hazard can occur leading to serious injury or death.**
- **Do not install unit in an area where flammable materials are present due to risk of explosions that can cause serious injury or death.**

Refrigerant gas may produce toxic gas if it comes in contact with fire from a fan, heater, stove, cooking device, or other heat source. Exposure to this gas can cause severe injury or death.

- **If equipment utilizing a burner is used in the same room as the air conditioner, there is the danger of oxygen deficiency which can lead to an asphyxiation hazard resulting in serious injury or death.** Be sure to sufficiently ventilate the room to avoid this hazard.
- **Any abnormalities in the operation of the air conditioner, such as smoke or fire, can result in severe injury or death. Turn off the power and contact your dealer immediately for instructions.**
- **If equipment utilizing a burner is used in the same room as the air conditioner, there is the danger of oxygen deficiency which can lead to an asphyxiation hazard resulting in serious injury or death.** Be sure to sufficiently ventilate the room to avoid this hazard.
- **After completing the installation work, check that the refrigerant gas does not leak.** Refrigerant gas may produce toxic gas if it comes in contact with fire from a fan, heater, stove, cooking device, or other heat source. Exposure to this gas can cause severe injury or death.

- **Do not ground units to water pipes, telephone wires, or lightning rods because incomplete grounding can cause a severe shock hazard resulting in severe injury or death. Do not ground units to gas pipes because a gas leak can result in an explosion which could lead to severe injury or death.**
- **Children playing with plastic bags face the danger of death by suffocation.**
Tear apart and throw away plastic packaging bags so that children cannot play with them.

 **WARNING**

- **Ask your dealer or qualified personnel to carry out installation work. Do not try to install the machine by yourself.**
Improper installation may result in water leakage, electric shocks, or fire.
- **Perform installation work in accordance with this installation manual.**
Improper installation may result in water leakage, electric shocks, or fire.
- **Be sure to use only the specified accessories and parts for installation work.**
Failure to use the specified parts may result in water leakage, electric shocks, fire, or the unit falling.
- **Check the unit stand for damage on a continual basis, especially if it has been used for a long time.**
If left in a damaged condition, the unit may fall and cause injury.
- **Do not touch the air outlet or the horizontal louvers while the swing louver is in operation as fingers may get caught and injured.**
- **Carry out the specified installation work after taking into account strong winds, typhoons, or earthquakes.**
Improper installation work may result in the equipment falling and causing accidents.
- **Make sure that a separate power supply circuit is provided for this unit and that all electrical work is carried out by qualified personnel according to local laws and regulations, and this installation manual.**
An insufficient power supply capacity or improper electrical construction may lead to electric shocks or fire.
- **Make sure that all wiring is secured, the specified wires are used, and that no external forces act on the terminal connections or wires.**
Improper connections or installation may result in fire.
- **When wiring the power supply and connecting the remote controller wiring and transmission wiring, position the wires so that the electric parts box lid can be securely fastened.**
Improper positioning of the electric parts box lid may result in electric shocks, fire, or the terminals overheating.
- **Before touching electrical parts, turn off the unit.**
- **Be sure to establish a ground.**
Do not ground the unit to a utility pipe, arrester, or telephone ground.
Incomplete ground may cause electrical shock, or fire.
A high surge current from lightning or other sources may cause damage to the air conditioner.
- **Do not touch the switch with wet fingers.**

Touching a switch with wet fingers can cause electric shock.

- **Be sure to install a ground leakage breaker.**
Failure to install a ground leakage breaker may result in electric shocks, or fire.
- **Do not install the air conditioner in the following locations:**
 - (a) Where a mineral oil mist or oil spray or vapor is produced, for example, in a kitchen.
Plastic parts may deteriorate and fall off or result in water leakage.
 - (b) Where corrosive gas, such as sulfurous acid gas, is produced.
Corroding copper pipes or soldered parts may result in refrigerant leakage.
 - (c) Near machinery emitting electromagnetic waves
Electromagnetic waves may disturb the operation of the control system and result in a malfunction of the equipment.
- **Do not allow children to play on or around the unit as they could be injured.**
- **Placing a flower vase or other containers with water or other liquids can result in a shock hazard or fire if a spill occurs.**
- **Do not remove the front panel because some parts are dangerous to touch. In addition, some parts may be damaged.** For checking and adjusting internal parts, contact your dealer.
- **Do not put a finger or other objects into the air inlet or air outlet. The fan is rotating at high speed and injury can result.**

 **CAUTION**

- **Ensure proper drainage by installing drain pipe with thermal insulation to prevent condensate.**
Improper drain pipe may result in water leakage and property damage.
- **Be very careful about product transportation.**
Some products use PP bands for packaging. Do not use any PP bands for a means of transportation. It is dangerous.
- **Do not turn off the power immediately after stopping operation.**
Always wait at least 5 minutes before turning off the power. Otherwise, water leakage or other problems may occur.
Take adequate measures to prevent the outdoor unit from being as a shelter by small animals.

 **NOTE**

- **Install the indoor and outdoor units, power supply wiring, and connecting wires at least 3.5 ft. away from televisions or radios in order to prevent image interference or noise.**
(Depending on the radio waves, a distance of 3.5 ft. may not be sufficient to eliminate the noise.)
- **Remote controller (wireless kit) transmitting distance is shorter than expected in rooms with electronic fluorescent lamps**

Install the indoor unit as far away from fluorescent lamps as possible.

- **Arrange the drain hose to ensure smooth drainage. Incomplete drainage may cause leaks in the building and on furniture.**
 - **Radio interference may result if installed too close to other electrical devices.**
 - **Dismantling of the unit, and treatment of the refrigerant, oil, and other parts, should be done in accordance with the relevant local and national regulations.**
-

2. BEFORE INSTALLATION

- **When moving the unit while removing it from the packing case, be sure to lift it by the four hanger brackets. Avoid putting any pressure on other parts especially the refrigerant piping.**
- Be sure to check the type of R-410A refrigerant to be used before installing the unit as using an incorrect refrigerant will prevent normal operation of the unit.
- The accessories needed for installation must be retained in your custody until the installation work is completed. Do not discard them!
- Decide upon a line of transport.
- Leave the unit inside its packaging until reaching the installation site. Where unpacking is unavoidable, use a sling of soft material or protective plates together with a rope when lifting, to avoid damage or scratches to the unit.
- When moving the unit after opening, hold the unit by the hanger brackets (× 4). Do not apply force to the refrigerant piping, drain piping or plastic parts.
- For the installation of an outdoor unit, refer to the installation manual attached to the outdoor unit.
- Do not install or operate the unit in the following areas:
 - **Kitchens or rooms that might be laden with mineral oil, or filled with oil vapor or spray. Plastic parts may deteriorate and eventually cause the unit to fall out of place or leaks.**
 - **Where sulfurous or other corrosive gas exists. Copper tubing and brazed spots may corrode and lead to refrigerant leaks.**
 - **Where machines generate electromagnetic waves and cause the control system to malfunction.**
 - **Where the air contains high levels of salt as near the ocean, and where voltage fluctuates greatly as in factories.**
- **Also in vehicles or vessels.**
- This unit, both indoor and outdoor, is suitable for installation in a commercial and light industrial environment. If installed as a household appliance, it could cause electromagnetic interference.

WARNING





- Entrust installation to the place of purchase or a qualified serviceman. Improper installation can result in leaks or even electric shock or fire.
 - Use of unspecified parts could result in the unit falling, leaks, or even electric shock or fire.
-






NOTE



- Be sure to read this manual before installing the indoor unit.
 - Be sure to procure an air filter in the field and mount it in the suction air passage to prevent water leaks or other problems.
-

2-1 ACCESSORIES

Check that the following accessories are included with your unit.

Name	(1) Drain pipe	(2) Metal clamp	(3) Washer for hanger bracket	(4) Clamp
Quantity	1 pc.	1 pc.	8 pcs.	9 pcs.
Shape				

Name	(5) Paper pattern for installation	Insulation pipe cover	Sealing pad
Quantity	1 pc.	1 each	1 each
Shape		(6) For gas pipe  (7) For liquid pipe 	(8) Large  (9) Small 

Name	(10) Resin bush	(11) Insulating tube	(Other) • Operation manual • Installation manual
Quantity	1 pc.	3 pcs.	
Shape		For wire 	

2-2 OPTIONAL ACCESSORIES

- The remote controller part numbers options . are shown in the following Table 1:
- Select a wired or wireless remote controller according to customer request and install in an appropriate place.

Table 1

Remote controller	
Wired type	BRC1D71
Wireless type	BRC7E83

NOTE

- If you wish to use a remote controller that is not listed in Table 1, select a suitable remote controller after consulting catalogs and technical materials.

FOR THE FOLLOWING ITEMS, TAKE SPECIAL CARE DURING CONSTRUCTION AND CHECK AFTER INSTALLATION IS FINISHED.

a. Items to be checked after completion of work

Items to be checked	Results of improper installation:	Check
Are the indoor and outdoor unit fixed firmly?	Units may drop, vibrate, or make noise.	
Is the gas leak test finished?	Insufficient cooling.	
Is the unit fully insulated?	Condensate water may drip.	
Does drainage flow smoothly?	Condensate water may drip.	

Does the power supply voltage correspond to that shown on the name plate?	The unit may malfunction or the components burn out.	
Are wiring and piping correct?	The unit may malfunction or the components burn out.	
Is the unit safely grounded?	Electric shock.	
Is wiring size according to specifications?	The unit may malfunction or the components burn out.	
Is something blocking the air outlet or inlet of either the indoor or outdoor units?	Insufficient cooling.	
Are refrigerant piping length and additional refrigerant charge noted down?	The refrigerant charge in the system is not clear.	

b. Items to be checked at time of delivery

* Also review the **SAFETY CONSIDERATIONS**

Items to be checked	Check
Did you explain about operations while showing the operation manual to your customer?	
Did you give the instruction manual to your customer?	

2-3 NOTE TO THE INSTALLER

Be sure to instruct customers how to properly operate the unit (especially cleaning filters, operating different functions, and adjusting the temperature) by having them carry out operations themselves while looking at the manual.

3. SELECTING INSTALLATION SITE

Attach an additional insulation pipe cover to the unit body when it is believed that the relative humidity in the ceiling exceeds 80%. Use glass wool, polyethylene foam, or something similar with a minimum 3/8 inch thickness as insulation.

(1) Select an installation site where the following conditions are fulfilled:

- Optimum air distribution can be ensured.
- Nothing blocks air passage.
- Condensate can be properly drained.
- Ceiling is strong enough to bear the indoor unit weight.
- False ceiling is not noticeably on an incline.
- Sufficient clearance for maintenance and service can be ensured.


DANGER

- Do not install unit in an area where flammable materials are present due to risk of explosion resulting in serious injury or death.

WARNING

- If the supporting structural members are not strong enough to take the unit's weight, the unit could fall out of place and cause serious injury.


(1-1) When a margin is in the space of the * section, service and maintenance work will become still easier if it vacates 7 7/8 in. or more.



- (1-2) Ensure that the pipe between indoor and outdoor units is within the allowable limit. Refer to the installation manual for the outdoor unit.
- (1-3) Install the indoor and outdoor units, power wire, and connecting wires at least 3.5 ft. away from televisions or radios in order to prevent image interference or noise. Depending on the radio waves, a distance of 3.5 ft. may not be sufficient enough to eliminate the noise.
- (2) Use suspension bolts for installation. Check if the ceiling is strong enough to support the weight of the unit. If there is a risk, reinforce the ceiling before installing the unit. Installation pitch is marked on the paper pattern for installation. Refer to it to check for points requiring reinforcing.
- (3) This product may be installed on ceilings up to 10.6 feet from the floor.
- (4) A direction of installation.
 - Refrigerant piping: the rear side, right side, or upper part.
 - Wiring: only the rear side.
 - Drain piping: the rear right side or the right side. Installation is not possible at rear left.

4. PREPARATIONS BEFORE INSTALLATION

- (1) Relative position of holes for indoor unit, suspension bolt position, piping, and wiring.



Model	A	B	C	D	E	F	G	H
FXHQ12MVJU	37 13/16	36 1/4	14 3/4	12 1/4	13 3/4	9 5/8	13 3/8	15 1/4
FXHQ24MVJU	55 1/8	53 1/2	23 1/2	20 7/8	22 3/8	18 1/4	22	23 15/16
FXHQ36MVJU	62 5/8	61	27 3/16	24 5/8	26 1/8	22	25 3/4	27 11/16

- (2) Drill holes for suspension bolts, refrigerant, drain pipe, and wire.
 - Refer to the paper pattern for installation.
 - Select the location for each of the holes and make the holes in the ceiling.
- (3) Remove the parts from the indoor unit.
 - (3-1) Detach the suction grille.
 - Slide the locking knobs (x2) on the suction grille inward (direction of arrows) and lift upwards. (Refer to Fig. 1)
 - With the suction grille open, remove the suction grille forward, holding on to the rear tabs (x2) on the suction grille. (Refer to Fig. 2)




Fig. 1







Fig. 2

- (3-2) Remove the decoration panels (left and right) and the protection net.
- After removing the securing screws for the decoration panels (one each), pull them forward in the direction of the arrow and remove them. (Refer to Fig. 3)
 - Remove the securing screws for the protection net. (Refer to Fig. 3)




- Raise one side of the protection net upward in the direction of the arrow (i) and remove back toward the arrow (ii). (Refer to Fig. 4, 5) Take out the accessories.





- (3-3) Remove the rear metal plate for transmission wire, remote controller wire and refrigerant pipe.
- It is necessary to drill the knock out hole in the removable part. Knock down several times with a punch and hammer and remove the removable part with pliers.

- When setting the refrigerant pipe to the rear side, remove the securing screws and the metal plate. (Refer to Fig. 6)




- (3-4) Remove the hanger brackets.
- Loosen the 2 bolts (M8) used to attach the hanger brackets which are on each side (4 places left and right) to within 3/8 in.. (Refer to Fig. 7, 8)
 - After removing the securing screws (M5) for the hanger brackets on the rear side, pull the hanger brackets back in the direction of the arrow, and remove them. (Refer to Fig. 8)



- (4) Attach the suspension bolts. Use suspension bolts which are W3/8 or M8-M10 in size.
- Adjust the distance of the suspension bolts from the ceiling in advance. (Refer to Fig. 9)

- NOTE**
- Use a hole-in anchor for existing ceilings, and a sunken insert, sunken anchor or other field supplied parts for new ceilings to reinforce the ceiling to bear the weight of the unit. Adjust clearance from the ceiling before proceeding further.



5. INDOOR UNIT INSTALLATION

It may be easier to attach accessory parts before installing the indoor unit. Therefore, please also read the instruction manuals provided with the accessory parts.

As for the parts to be used for installation work, be sure to use the provided accessories and specified parts designated by Daikin AC.

(1) **Secure the hanger brackets to the suspension bolts. (Refer to Fig. 10) Refer to Figure 10.**

NOTE

- To ensure they are safely secured, use the included washers, and secure them with double.

(2) **While sliding the main body from the front, lift it and insert the bolts (M8) for the hanger brackets into the attachment part on the hanger brackets. (Refer to Fig. 11)**

(3) **Fasten the bolts for the hanger brackets (M8) securely in 4 places, left and right. (Refer to Fig. 11)**

(4) **Replace the screws for the hanger brackets which had been removed (M5) securely in 2 places left and right. This is necessary to prevent any forward and back slide in the main body of the indoor unit. (Refer to Fig. 11)**




Fig. 10




Fig. 11

(5) **When hanging the indoor unit main body, be sure to use a level or a plastic tube with water in it to make sure the drain piping is set either level or slightly tilted to ensure proper drainage. Refer to Fig. 12**




Fig. 12

A. When the drain piping is tilted to the right, or to the right and back, do the following:

Place it level, or tilt it slightly to the right or the back. (1° or less.)

B. When the drain piping is tilted to the left, or to the left and back, do the following:

Place it level, or tilt it slightly to the left or the back. (1° or less.)

CAUTION

- Setting the unit at an angle opposite to the drain piping might cause a water leakage.

6. REFRIGERANT PIPING WORK

DANGER

- Refrigerant gas may produce toxic gas if it comes in contact with fire such as from a fan, heater, stove or cooking device. Exposure to this gas could result in severe injury or death.

CAUTION

- Use a pipe cutter and flare suitable for the type of refrigerant.
- To prevent dust, moisture, or other foreign matter from infiltrating the tube, either pinch the end or cover it with tape.
- Do not allow anything other than the designated refrigerant, such as air, to get mixed into the refrigerant circuit. If any refrigerant gas leaks while working on the unit, immediately ventilate the room thoroughly

6-1 GENERAL INSTRUCTIONS

- For refrigerant pipe of outdoor units, see the installation manual attached to the outdoor unit.
- Execute thermal insulation work completely on both sides of the gas pipe and the liquid pipe or a water leak may occur.

(The temperature of the gas pipe can reach up to approximately 250°F, so use insulation pipe cover that is sufficiently resistant.)

- In cases where the temperature and humidity of the refrigerant pipe sections might exceed 86°F or RH 80%, reinforce the thermal insulation (3/4 in. or thicker) or condensate may form on the surface of the insulation pipe cover.

Before refrigerant pipe work, check which type of refrigerant is used. Proper operation is not possible if the types of refrigerant are not the same.

6-2 CONNECTING THE REFRIGERANT PIPE

- Ensure outdoor unit is charged with refrigerant.
- Use copper alloy seamless pipes.
- Be sure to use both a spanner and torque wrench together, as shown in the drawing, when connecting or disconnecting pipes to/from the unit. (Refer to Fig. 13)
- Refer to Table 2 to determine the proper tightening torque.
- Refer to Table 2 for the dimensions of flare shape.
- When connecting the flare nut, coat the flare section (both inside and outside) with ester oil or ether oil, rotate three or four times first, then screw in. (Refer to Fig. 14)




Fig. 13

- Use the flare nut include with the main body of the unit.

CAUTION

- Oil must not adhere to any equipment other than a flare. If oil adheres to resin or other parts, deterioration may occur.




Fig. 14

Table 2

Pipe size (in.)	Tightening torque (ft.lbf)	Flare dimensions A (in.)	Flare shape (in.)
φ1/4	10.4–12.7	0.342–0.358	
φ3/8	24.1–29.4	0.504–0.520	
φ1/2	36.5–44.5	0.638–0.654	
φ5/8	45.6–55.6	0.760–0.776	

CAUTION

- Overtightening may damage the flare and cause a refrigerant leakage.

Not recommended but in case of emergency

You must use a torque wrench but if one is not available, you can use the following installation method: When you keep tightening the flare nut with a spanner, there is a point where the tightening torque suddenly increases. From that position, further tighten the flare nut the angle shown below:

Table 3

Pipe size (in.)	Further tightening angle	Recommended arm length of tool (in.)
φ1/4	60 to 90 degrees	Approx. 5 7/8
φ3/8	60 to 90 degrees	Approx. 7 7/8
φ1/2	30 to 60 degrees	Approx. 9 13/16
φ5/8	30 to 60 degrees	Approx. 11 13/16

After the work is finished, make sure to check that there is no gas leak.

6-3 BRAZING REFRIGERANT PIPING

- Do not use flux when brazing refrigerant pipe. Use phosphor copper brazing filler metal (BCuP) which does not require flux.
- Flux has an extremely negative effect on refrigerant piping systems. For instance, if chlorine based flux is used, it will cause pipe corrosion. If the flux contains fluorine, it will damage the refrigerant oil.
- Before brazing local refrigerant pipe, nitrogen gas shall be blown through the pipe to expel air from the pipe. If brazing is done without nitrogen gas blowing, a large amount of oxide film develops inside the pipe which can cause system malfunction.
- When brazing the refrigerant pipe, only begin brazing after having carried out nitrogen substitution or while inserting nitrogen into the refrigerant pipe. Once this is done, connect the indoor unit with a flared or a flanged connection.
- Nitrogen should be set to 2.9 psi with a pressure-reducing valve if brazing while inserting nitrogen into the pipe. (Refer to Fig. 15)




Fig. 15

⚠ DANGER

- Use of oxygen may cause an explosion resulting in serious injury or death. Only use nitrogen gas.

⚠ CAUTION

- Be sure to insulate any field piping all the way to the piping connection inside the unit. Any exposed piping may cause condensate or a burn if touched.

6-4 PIPING INSULATION

- Make absolutely sure to execute thermal insulation works on the pipe-connecting section after checking gas leakage by thoroughly studying the following figure and using the insulation pipe cover (6) and (7). Fasten both ends with the clamps (4). **(Refer to Fig. 16)**
- Wrap the small sealing pad (9) only around the insulation for the joints on the gas piping side. **(Refer to Fig. 16)**






Fig. 16

(1) For rear-facing piping:

- Remove the rear metal plate for pipe. **(Refer to Fig. 17)**
- The figure shows when both the piping and drain pipe are set facing the back.

When setting the piping to face up or right, attach the rear metal plate for refrigerant pipe and plug a hole for drain pipe. See Page 186, Section 4. PREPARATIONS BEFORE INSTALLATION, (3-3).

(2) For piping facing up.

- When setting the piping to face up, the L-shaped branch pipe kit sold separately is required.
- Removing the top penetration lid and use the L-shaped branch pipe kit sold separately to set the pipe. **(Refer to Fig. 18, 19)**

(3) For piping facing right.

- Cut out a slit hole on the decoration panel (right) and set the pipe. **(Refer to Fig. 17)**




Fig. 17




Fig. 18 (A figure from an inside bottom)




Fig. 19




Fig. 20 (A figure from an inside bottom)


- When piping is complete, use sissors to cut the removed penetration lid into the shape of the pipe and attach. As when removing the top penetration lid, secure the lead lines for the swing motor and thermistor by passing them through the clamp section on the top penetration lid. **(Refer to Fig. 18, 20)**

- When doing this, block any gaps between the pipe penetration lid and the pipes by using putty to prevent dust from entering the indoor unit.

7. DRAIN PIPING WORK



(1) Carry out the drain piping.

- Make sure piping provides proper drainage.
- You can select whether to bring the drain piping out from the rear right or right. For rear right-facing and right-facing situations, refer to Section 6. **REFRIGERANT PIPING WORK** on Page 188.
- Make sure the pipe diameter is the same or bigger than the branch piping using vinyl-chloride piping, nominal diameter 1 in., external diameter 1 1/4 in.
- Make sure the piping is short, has at least a 1/100 slope, and can prevent air pockets from forming. **(Refer to Fig. 21)**
- Do not allow any slack to gather in the drain pipe inside the indoor unit as slack in the drain pipe can cause the suction grille to break.



CAUTION


- Water accumulating in the drain piping can cause the drain to clog.
- Be sure to use the drain pipe (1) and metal clamp (2). Insert the drain pipe completely into the drain socket, and securely attach the metal clamp bracket inside the gray tape area on the inserted tip of the drain pipe. **(Refer to Fig. 22)** Screw the screws on the metal clamp bracket until there is 5/32 in. left. Pay attention to the direction of the attachment to prevent the metal clamp bracket from coming into contact with the suction grille. **(Refer to Fig. 23)**




- Insulate the metal clamp bracket and drain pipe from the bottom using the large sealing pad (8). **(Refer to Fig. 23)**
- Be sure to insulate all drain piping running indoors.

NOTE

- To ensure no excessive pressure is applied to the drain pipe (1), do not bend or twist when installing or leakage can occur.
- If converging multiple drain pipes, install according to the procedure shown below.



Select converging drain pipes with gauges suitable for the unit's operating capacity.



(2) Check to make sure the water flows smoothly after piping is complete.

- Slowly pour 600ml of drain-checking water into the drain pan through the air outlet.




Fig. 25

CAUTION

- If water collects on drain pipe it will cause blockage.

8. ELECTRIC WIRING WORK

8-1 GENERAL INSTRUCTIONS

- All field-supplied parts, materials, and electrical works must conform to local codes.
- Use only copper wire .
- For electrical wiring work, refer to the **Wiring Diagram Label** attached to the control box lid.
- For remote controller wiring details, refer to the installation manual attached to the remote controller.
- All wiring must be performed by an authorized electrician.
- This system consists of multiple indoor units. Mark each indoor unit as unit A, unit B, and so on, and be sure the terminal board wiring to the outdoor unit and BS unit are properly matched. If controls wiring and piping between the outdoor and indoor units are mismatched, a communications malfunction is likely.
- An ground leakage circuit breaker capable of shutting down the power supply to the entire system must be installed.
- Refer to the installation manual attached to the outdoor unit for the size of power supply wiring connected to the outdoor unit, the capacity of the circuit breaker and switch, and wiring instructions.
- Be sure to ground the air conditioner.

DANGER

- Do not ground units to water pipes, telephone wires, or lightning rods because incomplete grounding can cause a severe shock hazard resulting in severe injury or death. Do not ground to gas pipes because a gas leak can result in an explosion leading to severe injury or death.

8-2 ELECTRICAL CHARACTERISTICS

Model	Units			Power supply		Fan motor	
	Hz	Volts	Voltage range	MCA	MFA	W	FLA
FXHQ12MVJU	60	208-230V	Max. 253V Min. 187V	0.8	15	62	0.6
FXHQ24MVJU				1.0	15	130	0.8
FXHQ36MVJU				1.4	15	130	1.1

MCA: Min. Circuit Amps (A); MFA: Max. Fuse Amps (A)
W: Fan Motor Rated Output (W); FLA: Full Load Amps (A)

8-3 SPECIFICATIONS FOR FIELD SUPPLIED FUSES AND WIRES

Model	Power supply wiring		Remote controller wiring Transmission wiring	
	Field fuses 	Size	Wire	Size
FXHQ12MVJU	15A	Wire size must comply with local codes	2 conductor, stranded copper, non-shielded, PVC or vinyl jacket wire	AWG18-16
FXHQ24MVJU				
FXHQ36MVJU				

Allowable length of transmission wire between indoor/outdoor units and between the indoor unit and the remote controller wire are as follows.

- (1) Outdoor unit – Indoor unit:
Max. 3280 ft. (Total wire length: 6560 ft.)
- (2) Indoor unit – Remote controller:
Max. 1640 ft.

9. WIRING EXAMPLE AND HOW TO SET THE REMOTE CONTROLLER

9-1 HOW TO CONNECT WIRES

CAUTION

- Even if the control box lid is removed, pull the remote controller wire, transmission wire, and the power supply wire inside the unit, using conduits for each, so that the wires do not come into contact with the opening section of the metal casing.
- Pass conduits through the wall and secure them along with the refrigerant pipe in order to prevent external pressure to transmission wire and power supply wire.
- Prevent dust from entering into the unit by filling the gap around the pipe or wire with corking or putty.
- Arrange the wires and fix the lid firmly so that it does not float during wiring work.
- Do not clamp remote controller wire and transmission wire together with power supply wire. Doing so may cause malfunction.
- Remote controller wire, transmission wire, and power supply wire should be located at least 5 inches from other electrical wires. Not following this guideline may result in malfunction due to electrical noise.

Method of wiring power supply, units, and connecting remote controller wiring: (Refer to Fig. 27)

- Attach the plastic bushing (10) for remote controller wiring.
- Insert the conduit for power supply wire in the conduit hole, and fix it with the lock nut.




Fig. 26

- **Power supply wire**
Holding the control box lid, loosen the 2 securing screws, remove the control box lid, match up the phases on the power supply terminal block inside (2P), and make the connections. After this is done, use the attached clamp (4) to bind wire between units to the anchor point. (Refer to Fig. 28)
- **Remote controller wire and transmission wire**
Holding the control box lid, loosen the 2 securing screws, remove the control box lid. Thread the remote controller wire and transmission wire through the conduit (11), secure with the clamp (4), and cut off conduit (11) to suitable length. The conduit (11) can let the wire pass to a maximum of 2 wires. If there are three or more wires, use another conduit (11). Pull the wires inside through plastic bushing and connect the wires to the transmission terminal block (6P inside the control box). After connecting, use the clamp (4) to bind the remote controller

wire together with the transmission wire to the anchor. (Refer to Fig. 27, 28, 29)




Fig. 27




Fig. 28




Fig. 29

- The conduit (11) allows the remote controller wire and transmission wire pass to a maximum of 2 wires.

! WARNING


- Never connect power supply wiring to the terminal block for remote controller wiring as this could damage the entire system.
- Use only specified wire and connect wires to the terminal tightly. Be careful wires do not place external stress on terminals. Keep wires in neat order so as to not obstruct other equipment. Make sure that the electric box lid fits tightly. Incomplete connections could result in overheating and, in worse cases, result in electric shock or fire.

CAUTION


- To avoid a short circuit in the electric parts box, be sure to apply sealing material or putty (not included) to the wiring hole to prevent the infiltration of water, insects, or other small creatures.

NOTE

- Use round crimp-style terminals for connecting wires to the power-supply terminal block. If unavailable, observe the following points when wiring.
 - Do not connect wires of different gauges to the same power supply terminal. Looseness in the connection may cause overheating.
 - Use the specified electric wire. Connect the wire securely to the terminal. Lock the wire down without applying excessive force to the terminal. Tightening torque : 0.97 ft.lbf \pm 10%



Connect wires of the same gauge to both side.



- Tightening torque for the terminal screws.
 - Use the correct screwdriver for tightening the terminal screws. If the blade of screwdriver is too small, the head of the screw might be damaged, and the screw will not be properly tightened.
 - If the terminal screws are tightened too hard, screws might be damaged.
 - Refer to the table below for the tightening torque of the terminal screws.

Table 4


Terminal	Size	Tightening torque (ft.lbf)
Transmission terminal block (6P)	M3.5	0.58 – 0.72
Power supply terminal block (2P)	M4	0.87 – 1.06
Ground terminal	M4	0.87 – 1.06

- Do not connect wires of different gauges to the same ground terminal. Looseness in the connection may deteriorate protection.
- Outside of the unit, keep transmission wire at least 5 inches away from power supply wire. The equipment may malfunction if subjected to external electrical noise.
- For remote controller wire, refer to the **INSTALLATION MANUAL OF REMOTE CONTROLLER** attached to the remote controller.


9-2 WIRING EXAMPLE

- Fit the power supply wire of each unit with a switch and fuse as shown in the drawing.


COMPLETE SYSTEM EXAMPLE (3 systems)



1. When using 1 remote controller for 1 indoor unit. (Normal operation)



2. For group control or use with 2 remote controllers



3. When including BS unit




Fig. 33

NOTE

1. It is not necessary to designate an indoor unit address when using group control. The address is automatically set when power is activated.
2. All transmission wires except for remote controller wires are polarized and must match the terminal symbol.
3. A single switch can be used to supply power to units on the same system but branch switches and branch circuit breakers must be selected carefully.
4. Do not ground the equipment on gas pipes, water pipes, or lightning rods, or crossground with telephones. Improper grounding can result in electric shock.

10. ATTACHING THE SUCTION GRILLE, THE DECORATION PANELS AND THE PROTECTION NET

Once wiring is complete, firmly attach the control box lid, the suction grille, the decoration panels, and the protection net in the order opposite to detachment.

- Attach the protection net from the way of the hook (i), fix 2 securing screws of the middle of the other side first (ii), then fix the remaining securing screws (iii).




Fig. 34

11. FIELD SETTING

Make sure the control box lids are closed on the indoor and outdoor units, and turn on the power. Field setting must be made from the remote controller in accordance with the installation manual.

- Setting can be made by changing the **Mode No.**, **FIRST CODE NO.**, and **SECOND CODE NO.**
- For setting and operation, refer to the **FIELD SETTING** section in the installation manual of the remote controller.

11-1 SETTING AIR FILTER SIGN

- Remote controllers are equipped with liquid crystal display air filter signs to display when to clean air filters.
- Change the **SECOND CODE NO.** according to Table 5 depending on the amount of dirt or dust in the room. **SECOND CODE NO.** is factory set to [01] for air filter contamination-light.

Table 5

Setting	Spacing time of display air filter sign (long life type)	Mode No.	FIRST CODE NO.	SECOND CODE NO.
Air filter contamination-light	Approx. 2500 hrs	10 (20)	0	01
Air filter contamination-heavy	Approx. 1250 hrs			02

Wireless remote controllers:

- When using wireless remote controllers, a wireless remote-controller address setting is necessary. Refer to the instal

lation manual attached to the wireless remote controller for setting instructions.

11-2 CONTROLLING 1 INDOOR UNIT BY 2 REMOTE CONTROLLERS

- When using 2 remote controllers, one must be set to MAIN and the other to SUB.

MAIN/SUB CHANGEOVER

- (1) Insert a screwdriver into the recess between the upper and lower part of remote controller and, working from the two positions, pry off the upper part.
The remote controller PC board is attached to the upper part of remote controller. (Refer to Fig. 35)
- Turn the MAIN/SUB changeover switch on one of the two remote controllers PC boards to [S]. (Leave the switch of the other remote controllers set to [M].) (Refer to Fig. 36)




Fig. 35




Fig. 36

Wiring Method


See Section 8. **ELECTRICAL WIRING WORK** on page 192 and Section9. **WIRING EXAMPLE AND HOW TO SET THE REMOTE CONTROLLER** on pages 192 to 195.

- (2) Remove the control box lid.
Add 2nd remote controller to the transmission terminal block (P1, P2) in the control box. (There is no polarity.)
(Refer to Fig. 29 on page 193 and Table 4 on page 194.

11-3 COMPUTERIZED CONTROL (FORCED OFF AND ON/OFF OPERATION)

1. Wire specifications and how to perform wiring:

- Connect the input from outside to terminals T1 and T2 of the terminal block for remote controller..



Wire specification	2-conductor, stranded, non-shielded copper cable / PVC or vinyl jacket
Gauge	AWG 18
Length	Max. 328 ft.
External terminal	Contact that can ensure the minimum applicable load of 15 V DC, 10 mA.

2. Actuation


- The following table explains FORCED OFF and ON/OFF OPERATIONS in response to Input A. The T1-T2 terminals are standard on all Daikin indoor units and allow for remote starting and stopping of equipment. Individual indoor units can be field programmed at the remote controller to change the T1-T2 sequence of operation of the equipment based upon the application.

<p>FORCED OFF (Manual Restart)</p> <p>Mode No. 12 First Code No. 1 Second Code No. 01</p> <p>DEFAULT SETTING</p>	<p>ON/OFF OPERATION</p> <p>Mode No. 12 First Code No. 1 Second Code No. 02</p>
<p>Input A OFF (Open Circuit)</p> <p>An open circuit between terminals T1 and T2 allows the unit to run normally.</p>	<p>Input A OFF (Open Circuit)</p> <p>An open circuit between terminals T1 and T2 prevents unit operation.</p>
<p>Input A ON (Closed Circuit)</p> <p>Closing the normally open circuit between terminals T1 and T2 stops operation of the unit. When T1-T2 is opened, the unit must be restarted with the remote controller.</p>	<p>Input A ON (Closed Circuit)</p> <p>A closed circuit between terminals T1 and T2 allows normal operation of the unit.</p>

- How to select FORCED OFF and ON/OFF OPERATION Turn the power on and then use the remote controller to select operation. These codes are programmed at the remote controller. Individual unit groups can be programmed independently.

11-4 CENTRALIZED CONTROL

- For centralized control, it is necessary to designate the Group Number. For details, refer to the manual of each optional controllers for centralized control.



- Set the remote controller to the FIELD SET MODE. For details, refer to **HOW TO SET IN THE FIELD** in the remote controller manual.
- When in the FIELD SET MODE, select mode No. 12, then set the FIRST CODE NO. to [1]. Then set SECOND CODE NO. to [01] for FORCED OFF and [02] for ON/OFF OPERATION. (FORCED OFF at factory set)


12. TEST OPERATION

Refer to the section **TAKE SPECIAL CARE DURING CONSTRUCTION** on page 185.

- Make sure if the service lids are closed on the indoor and outdoor units.
- After finishing the construction of refrigerant pipe, drain pipe, and electric wire, conduct the check operation by referring to the installation manual of the outdoor unit.
- The operation lamp of the remote controller will flash when a malfunction occurs. Check the displayed malfunction code to identify the trouble. An explanation of malfunction codes and the corresponding trouble is provided in the installation manual of the outdoor unit.

If any of the items in Table 6 are displayed, there may be a problem with the wiring or power, so check the wiring again.

Table 6


Remote control display	Content
"  Under Centralized Control is lit	<ul style="list-style-type: none"> There is a short circuit at the FORCED OFF terminals (T1, T2).
U4 is lit UF is lit	<ul style="list-style-type: none"> The power on the outdoor unit is off. The outdoor unit has not been wired for power supply. Incorrect wiring for the transmission wiring and / or FORCED OFF wiring. The transmission wiring is cut.
No display	<ul style="list-style-type: none"> The power on the indoor unit is off. The indoor unit has not been wired for power supply. Incorrect wiring for the remote controller wiring, the transmission wiring and / or the FORCED OFF wiring. The remote controller wiring is cut.

- If U3 is lit up, the malfunction code shows the check operation has not been performed yet.


12-1 HOW TO DIAGNOSE FOR MALFUNCTION

With the power on, it is possible to monitor the type of malfunction by looking at the malfunction code displayed in the remote controller.

If nothing is displayed in the remote controller, check the following items before attempting a diagnosis based on the malfunction code, as they might be a cause.

- Disconnected or incorrect wiring (between power supply and the outdoor unit, between the outdoor and indoor units, and between the indoor unit and the remote controller)
- Burnt out indoor or outdoor unit fuse
- "  " will be displayed for a few seconds on the remote controller immediately after the power is turned on. This display indicates that the remote controller is being checked to see whether it is ok or not, and does not indicate a malfunction.




Diagnose with the display on the liquid crystal display remote controller.

1. With the wired remote controller:
When the operation stops due to trouble, the operation lamp flashes and the malfunction code is indicated in the liquid crystal display. In such a case, diagnose by referring to the table on the malfunction code list. In case of group control, the unit No. is displayed so that the indoor unit No. with the trouble can be recognized.
2. With the wireless remote controller:
Also refer to the operation manual attached to the wireless remote controller.
When operation stops, the display on the indoor unit flashes. Diagnose the malfunction code with the following procedures:
 - (1) Press the INSPECTION /TEST OPERATION button,  is displayed and [0] flashes.
 - (2) Press the PROGRAMMING TIME button and find the stopped unit No.
Number of beeps

3 short beeps	Perform all the following operations
1 short beep	Perform (3) and (6)
1 long beep	No trouble
 - (3) Press the OPERATION MODE SELECTOR button and upper flashing malfunction code.
 - (4) Continue pressing the PROGRAMMING TIME button until it makes 2 short beeps, and find the upper code.
 - (5) Press the OPERATION MODE SELECTOR button and lower figure of the flashing malfunction code.
 - (6) Continue pressing the PROGRAMMING TIME button until it makes a long beep, and find the lower code. **A long beep indicates the malfunction code requires attention.**

NOTES:

1. Using a wired remote controller: Press the INSPECTION / TEST OPERATION button on remote controller till starts flashing.
2. While in inspection mode, hold down the ON/OFF button for 5 seconds or longer till the above trouble history disappears. After the trouble code goes on and off twice the (normal) code is displayed.

Order	Operation
(1)	Open gas-side stop valve.
(2)	Open liquid-side stop valve.
(3)	Electrify crank case heater for 6 hours.
(4)	Set to cooling with the remote controller and push " ON/OFF " button to start operation.
(5)	Push "  /TEST " button twice and operate in TEST OPERATION MODE for 3 minutes.
(6)	Push "  /SWING " button and confirm its operation.
(7)	Push "  /TEST " button and operate normally.
(8)	Confirm its function according to the operation manual.

12-2 MALFUNCTION CODE

- For places where the malfunction code is left blank, the indication is not displayed. The shaded areas indicate when the unit does not display a malfunction code and continues running even though it might need attention. Be sure to inspect the system and make repairs as necessary.
- Depending on the type of indoor or outdoor unit, the malfunction code may or may not be displayed.





Code	Malfunction/Remarks
A1	Micro-computer in PCB is not working
A3	Drain level is too high
A6	Fan motor error
A7	Swing louver motor error
A9	Electronic expansion valve drive error
AJ	Capacity setting error
C4	Resistance of indoor unit heat exchanger is abnormal.
C5	Sensor R3T for heat exchanger temperature impaired
C9	Resistance of indoor unit suction-air thermistor is abnormal.
CJ	Sensor for remote controller impaired
	Resistance of the remote controller thermistor is abnormal.
E3	Abnormally high pressure (outdoor unit)
E4	Abnormally low pressure (outdoor unit)
E5	Compressor overheats
E7	Outdoor fan motor locks
E9	Electronic expansion valve impaired (outdoor unit)
F3	Outdoor unit discharge temperature is too high
F6	Overcharged refrigerant
H9	Outdoor air thermistor impaired (outdoor unit)
J3	Discharge pipe thermistor impaired (outdoor unit)
J5	Suction pipe thermistor impaired (outdoor unit)
J6	Heat exchanger thermistor impaired (outdoor unit)
J9	Sensor for heat exchanger impaired
JA	Sensor for high pressure impaired
JC	Sensor for low pressure is fault.
L4	Overheating radiation fin or excessive temperature in power transistor (outdoor)






L5	Instantaneous overcurrent (outdoor)
	Compressor motor grounded or short circuit; inverter PCB error
L8	
	Compressor overcurrent or compressor motor wire cut
L9	
	Compressor possibly locked
LC	Communication error between inverter and outdoor control unit
P1	Open-phase (outdoor)
P3	PC board temperature sensor malfunction (outdoor)
P4	Radiation fin temperature sensor error
PJ	
	Capacity setting error (outdoor) or nothing programmed in the data hold IC.
U0	Low pressure drop due to insufficient refrigerant or electronic expansion valve error.
U2	Power source voltage failure
U3	Failure to carry out check operation; transmission error
U4 UF	
	Communication error due to incorrect wiring between indoor unit and outdoor unit, or communication error between outdoor unit and BS unit. Failure to carry out check operation for indoor-outdoor or outdoor-outdoor communications.
U9	Communication error between indoor and outdoor unit, or BS unit and indoor/outdoor unit.
UA	
	Communication error of indoor/BS/outdoor unit; setting error of spare parts PCB when replaced.



11. Accessories

Standard Accessories

Check that the following accessories are included with your unit.

Name	(1) Drain pipe	(2) Metal clamp	(3) Washer for hanger bracket	(4) Clamp
Quantity	1 pc.	1 pc.	8 pcs.	9 pcs.
Shape				

Name	(5) Paper pattern for installation	Insulation pipe cover	Sealing pad
Quantity	1 pc.	1 each	1 each
Shape		(6) For gas pipe  (7) For liquid pipe 	(8) Large  (9) Small 

Name	(10) Resin bush	(11) Insulating tube	<ul style="list-style-type: none"> • Operation manual • Installation manual
Quantity	1 pc.	3 pcs.	
Shape		For wire 	

3PN06240-1H

Optional Accessories (For Unit)

No.	Item	Model	FXHQ12MVJU	FXHQ24MVJU	FXHQ36MVJU
1	Replacement long-life filter (Resin net)		KAFJ501D56	KAFJ501D112	KAFJ501D160
2	L-type piping kit (for upward direction)		KHFP5M35	KHFP5M63	KHFP5M160

3D049335

Op For optional accessories for Controllers, refer to the Controller manual.

Warning



- Daikin Industries, Ltd.'s products are manufactured for export to numerous countries throughout the world. Daikin Industries, Ltd. does not have control over which products are exported to and used in a particular country. Prior to purchase, please therefore confirm with your local authorized importer, distributor and/or retailer whether this product conforms to the applicable standards, and is suitable for use, in the region where the product will be used. This statement does not purport to exclude, restrict or modify the application of any local legislation.
- Ask a qualified installer or contractor to install this product. Do not try to install the product yourself. Improper installation can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Use only those parts and accessories supplied or specified by Daikin. Ask a qualified installer or contractor to install those parts and accessories. Use of unauthorized parts and accessories or improper installation of parts and accessories can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Read the User's Manual carefully before using this product. The User's Manual provides important safety instructions and warnings. Be sure to follow these instructions and warnings.

If you have any inquiries, please contact your local importer, distributor and/or retailer.



© 2004 Daikin Industries, Limited.

Daikin®, Daikin AC™, Absolute Comfort™, VRV® and REFNET™ are trademarks pending or registered trademarks of Daikin Industries, Limited. All rights reserved. LowWorks® and LON® are registered trademarks of Echelon Corporation. BACnet® is a Data Communication Protocol for Building Automation and Control Networks, developed under the auspices of the American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE).



JMI-0107



JQA-1452

About ISO9001

ISO 9001 is a plant certification system defined by the International Organization for Standardization (ISO) relating to quality assurance. ISO 9001 certification covers quality assurance aspects related to the "design, development, manufacture, installation, and supplementary service" of products manufactured at the plant.



EC99J2044



JQA-E-90108

About ISO 14001

ISO 14001 is the standard defined by the International Organization for Standardization (ISO) relating to environmental management systems. Our group has been acknowledged by an internationally accredited compliance organisation as having an appropriate programme of environmental protection procedures and activities to meet the requirements of ISO 14001.

Dealer

DAIKIN AC (AMERICAS), INC.
1645 Wallace Drive, Suite 110
Carrollton, TX75006
info@daikinac.com
www.daikinac.com

©All rights reserved

● Specifications, designs and other content appearing in this brochure are current as of May 2007 but subject to change without notice.